

LEAD LINED GYP. BD.
PANELS - EXTEND
LEAD INTO FRAME

REFER TO WALL TYPE
PLAN FOR DESCRIPTION

2' HOLLOW METAL FRAME
W/LEAD SHIELDING -
2" ON LEAD LINED SIDE
1 3/8" ON CONTROL ROOM SIDE
ATTACH PER MFR.
RECOMMENDATIONS -
GROUT SOLID

LEADED GLASS-UNDERCUT
GLASS 1/8" ALL FOUR SIDES
DOUBLE SIDED FOAM TAPE
BETWEEN GLASS AND FRAME

1/2" x 1/2"
REMOVABLE GLAZING STRIPS

STEEL TELESCOPIC LEAD LINED WINDOW FRAMES
MATCH HOLLOW METAL DOOR FRAMES.
ADJUSTABLE TO WALL THICKNESS OF 4 1/4" TO 6".

LEADED GLAZING ADJ. SILL AND JAMB DETAIL